

Quanics

Engineering Water Solutions®

P.O. Box 1520
Crestwood, KY 40014
1-877-QUANICS
www.quanics.net

Installation Sheet


Gravity Recirculation Device

ATS-GRD-100/80/20




STEP 1 **Attach riser to tank.**
(May be twist locked onto a riser that's been poured into tank or retrofitted tank with a RB-RTA-26x2 tank adapter.)

STEP 2 **Level the assembly**
(Even distribution will not occur if assembly isn't level. Assembly will rotate using quick disconnects)



STEP 3
Adjust float to proper depth
(see graphic below) **Screw the rod assembly onto the bottom of the assembly, making sure rod stand pipe is vertical for proper float operation.**

STEP 4
Prime and glue inlet and outlet pipes to distribution assembly



Proper float height adjustment

