



P.O. Box 1520
Crestwood, KY 40014
1-877-QUANICS
www.quanics.net

Dear Valued Customer:

Thank you for purchasing a quality Quanics™ product. We do our very best to provide superior products and service to each of our customers. The following Installation and Maintenance sheet is part of this service. If you have any questions or concerns that are not addressed by this sheet, please give us a call.

New System Installation: All hanging models except the FPV-H34-A101.


A Quanics Access System is needed for installation, and may be required in some states.

There are two ways to install these pump vaults into a new system:

The first is with a Quanics **Cast-In Tank Adapter** (RB-TA-F-26 x 6). These parts are cast in the tank by the precaster.

If the precaster has not cast in an adapter you must install a Quanics **Retrofit Tank Adapter** (RB-TA-T-26 X 2).

Contact Quanics for details and to order.



- Notes:
- Each piece of PVC pipe should be four inches longer than the diameter of the outlet access opening.
 - For installation of a discharge system, Quanics has a separate instruction sheet that will be included in the package.

Note: The outlet access opening must be at least 16" ID.

Existing System Installation:

Same as New System Installation, except the tank will need to be pumped before the pump vault is installed.

- Notes:
- A Quanics **Retrofit Tank Adapter** (RB-TA-T-26x2) must be used if there is no cast in adapter. Call Quanics for details and to order.
 - A Quanics Access System is required for installation.
 - It is recommended, and may be required in certain states, to install risers to grade.

The product(s) shown are covered by one or more of the following patents:

U.S. 5,762,793; 5,580,453; 5,591,331; 5,759,393; 5,683,577; 5,582,716; 5,779,896; 5,593,584; 5,795,472; 5,736,035; 4,710,295; 5,382,357; 5,482,621
U.S. Des. 386,241; 349067; 4605501; 5098568; Des. 309007, Australia: 134440, Canada: 2,135,937, Israel: 111574, New Zealand: 264824,
Other Patents Pending

P.O. Box 1520
Crestwood, KY 40014

1-877-QUANICS
www.quanics.net


The interval for servicing septic tanks is set by state and local code. Throughout the United States there is a wide difference of opinion on what this interval should be, but most regulatory agencies suggest two to five years. The filter panels on the Quanics pump vault should be inspected and cleaned when the septic tank is normally inspected and pumped.

To service the filtered pump vault:

**Servicing any septic system should only be done by a certified septic tank pumper or installer.*


STEP 1

Locate the outlet access opening of the septic tank and remove the lid located over the pump vault.




STEP 2

The tank **does not** have to be pumped to clean the filter plates. If the tank does not need to be pumped go to step 3. If the tank needs to be pumped, lift up one of the filter panels, and pump the tank.




STEP 3

Completely insert the white maintenance plate behind the filter panel that is to be cleaned.



STEP 4

Remove the filter panel. Rinse the filter plate(s) with water, making sure all septage is rinsed back into the tank. The filter plate(s) should be clean until all slots are open and free of debris.



STEP 5

Replace the filter panel and remove the maintenance plate.

Repeat steps 3, 4 and 5 for the second filter panel.

