



**WATCH OUR HOW-TO VIDEO
ONLINE AT www.shrinkins.com**

1. Cut out the needed pattern from above.
2. Wrap the pattern around a spoke on the wheelchair. Spokes can vary in size, you may need to trim the length for a good fit. If needed, trim at the narrow end. Be sure when you wrap it around the spoke, the edges overlap.
3. Once the pattern is trimmed to size, place it on the backside of your shrinkins sheet. Be sure the cut lines run in the same direction, so your decoration will shrink correctly.
4. Trace around the pattern with your pen, then cut the piece out with scissors.
5. Lay your cut piece flat, with the design side facing up. Apply the tape along the angled edge. (Indicated on the pattern). Trim off the extra tape on both ends.
6. Rewrap the piece around the spoke and press the tape down.
7. Rotate the seam to the most hidden area and shrink carefully with the blow dryer. For best results, use light heat near the taped seam. Wrinkles will smooth with continued heat.