



Planer boards are made from wood stair treads purchased at home depot or lowes. 3 pieces of 28" inch (heavy gauge) rebar connect the boards by measuring from the end of each board and drilling a hole at the 3, 11 and 23.5 inch marks. An eye bolt is attached at the 29 inch mark 9 inches from the bottom. These boards will handle the worst the bay has to offer.