


# AromaMist® Ultrasonic Diffusing Mister INSTRUCTIONS

## PARTS



## FEATURES

AromaMist® uses ultrasonic vibrations to transform your essential oil and water into a healthy, fragrant mist.

1. Water Capacity: 115 mL (4 fl oz)
2. Suggested Room Size: 150-200 sq ft
3. Continuous Operation: Up to 3 hours
4. Intermittent Operation: Up to 6 hours at 15-second intervals
5. Light Mode: Rotating, solid color, OFF
6. Automatic safety shut-off (Mist only)
7. Power: AC adapter included, UL approved

## CARE & MAINTENANCE

Do not fill water into the diffuser from the Mist Outlet. Only use the power cord that is supplied with the unit. Always remove the power cord before cleaning. Essential oil should not come in contact with the exterior surface of the unit.

### TO CLEAN:

\* SpaRoom® KLENZOR™ tablets may be used to renew diffuser to like-new condition.

Remove Top Cover. Empty the water from the side of the tank. Do not empty water near the air outlet.

The Ceramic Disc should not come in contact with any hard or sharp objects.

To remove possible buildup, gently use a cotton swab dipped in white vinegar to wipe out the inside. A cleaning brush is included.

Dry with a soft cloth to avoid mineral buildup.

Do not use strong cleaning agents.

## INSTRUCTIONS FOR USE

1. Remove the Top Cover from the Main Body.
2. Fill the Water Tank up to Max Fill Line with cool tap water. Do not overfill or mist output may be low. Add a few drops of your choice of pure essential oil to the Water Tank.
3. Replace the Top Cover.
4. Connect the AC Adapter to the DC Plug on the back of the unit. Then plug the Adapter into the wall outlet.
5. **Button Functions:**

**Left Side – Light:**  
 1<sup>st</sup> push = rotating color  
 2<sup>nd</sup> push = maintains solid color  
 3<sup>rd</sup> push = turns lights OFF

**Right Side – Mist:**  
 1<sup>st</sup> push = continuous mist up to 3 hours  
 2<sup>nd</sup> push = intermittent mist up to 6 hours at 15-second intervals  
 3<sup>rd</sup> push = turns the mist function OFF
6. The unit will stop misting when water level becomes too low. Note that the light must be manually turned off.
7. Use only 100% pure essential oil.

