

# Quanics

Engineering **Water** Solutions

P.O. Box 1520  
Crestwood, KY 40014  
**1-877-QUANICS**  
[www.quanics.net](http://www.quanics.net)

## Installation Sheet

Carbon Filters

ATS-CF-1.25/2.0/3.0/4.0




### STEP 1

Apply PVC cement according to manufacturers directions to the base and vent pipe. Place carbon filter pad on the grid inside the base.

### STEP 2


Attach domed top by aligning the locking tabs with the locking slots on the base and twist clockwise to lock. You will hear a snap noise when fully engaged.



**Rooftop Installation**



**ATS-CF-RC-2.0**  
Replacement disk for  
1.25" & 2.0" Carbon Filter



**ATS-CF-RC-4.0**  
Replacement disk for  
3.0" & 4.0" Carbon Filter



**System Installation**

## Maintenance

1. Remove top domed section by turning the top counter clockwise.
2. Remove old carbon pad.
3. Place new carbon pad in base.
4. Attach domed top section. Twist clockwise until the snap lock noise is heard.

**Quanics recommends** replacing the carbon filter disk annually.