

1. Place tank adapter ring (RB-RTA-30) centered over septic tank access opening.
2. Drill four (4) 3/8" diameter anchor bolt holes 90° apart through adapter and into concrete lid. Center of holes should be 2" away from adapter wall allowing clearance for the riser (FIGURE 1).
3. Tap bolt anchors into holes thread side up with a hammer.
4. Take adapter off & apply a continuous and generous bead of adhesive (FIGURE 2) to the bottom of the adapter and place back on bolts in tank lid.
5. Secure with washers & nuts (avoid overtightening).
6. Install riser & lid onto adapter per instructions.

TOOLS NEEDED:

Caulk gun
Drill
3/8" concrete drill bit
3/8" Deep set socket and ratchet




FIGURE 1




FIGURE 2

